



How to Use a DUMP STATION

Dump stations are small essential facilities that help protect public health and the environment by ensuring the proper disposal of waste from the wastewater tanks of motor homes and caravans. You can find public dump stations (free of charge) in many towns, and most camping grounds will have one too.

The New Zealand Motor Caravan Association Inc. in partnership with KEA Campers NZ, offers financial assistance for the installation of public dump stations across New Zealand.



For further information visit www.nzmca.org.nz

ALWAYS USE DISPOSAL GLOVES

IN YOUR MOTORHOME

Open and close the toilet slide a few times so when you remove the cassette you won't get waste water over your hands and on the bottom of the cassette compartment.

STEP 1



REMOVE THE GRATE



STEP 2



This is to prevent waste blocking the grate holes when emptying the cassette. Keep the cap of the cassette well away from the hole in case it falls down the inlet pipe.

EMPTY THE CASSETTE

Remove the cassette cap and place away from the dump station. Place the nozzle down the inlet pipe and press the air release button to help empty the cassette.

STEP 3



RINSE THE CASSETTE

Use the water tap next to the dump station. This water is not suitable for drinking.


STEP 4



REPLACE THE GRATE AND WASH THE CASSETTE



STEP 5



EMPTY GREY / BLACK WATER WASTE VIA HOSE

Connect the hose at the motor home (first) and the arrow end to the bayonet fitting in the dump station (last). Check the fittings are secure, and then release the valve on the tank of the motor home.

If there is no bayonet fitting at the dump station you will need to hold the hose at the dump station end otherwise you risk spraying waste water everywhere. At some dump stations you will need to run your hands under the hose to help empty it.

STEP 6



Disconnect the hose from the motor home (first) and keep it lifted above the end connected to the dump station. Wash out the hose before disconnecting from the dump station end.

CLEANING UP FOR THE NEXT USER



STEP 7



Wash down the dump station and replace the cap. Close the lid and dispose of your gloves in a rubbish bin. **Remember to wash your hands thoroughly.**

Never use the water at a dump station to fill your fresh water tanks in case of contamination. Some dump stations may have a fresh water tap installed a few metres away.

